

ANALYTICAL TEST METHODS**“P”, “M”, “OH” ALKALINITY TEST
TITRATION METHOD****PROCEDURE:**

1. Measure 50 ml of the water to be tested in the graduated cylinder.
2. Pour into the casserole.
3. Add 3 drops of PHENOLPHTHALEIN INDICATOR SOLUTION to the casserole and stir.
4. If the water does not change to a pink color, there is no "P" Alkalinity present, and the reading is reported as "zero". If the water does change to a pink color, "P" Alkalinity is present and the test should be continued.
5. By squeezing the plastic bottle of the automatic burette, force the SULFURIC ACID SOLUTION slowly from the burette to just above the zero mark. Then allow the excess to drain back automatically into the plastic bottle.
6. While stirring the sample constantly, add the SULFURIC ACID SOLUTION slowly from the burette to the casserole until the pink color disappears and the water turns clear or resumes the original color of the sample before the PHENOLPHTHALEIN INDICATOR SOLUTION was added. This is the endpoint. Read the burette. The "P" Alkalinity is the burette reading multiplied by 20.
7. To the same sample without refilling the burette, add 3 to 4 drops of METHYL PURPLE INDICATOR SOLUTION to the casserole and stir.
8. If the water changes to a purple color, the "M" Alkalinity is equal to the "P" Alkalinity. If the water changes to a green color, "M" Alkalinity is present and the test should be continued.
9. While stirring the water constantly, add SULFURIC ACID SOLUTION slowly from the burette to the casserole until the green color changes to purple. This is the endpoint. Read the burette. The "M" Alkalinity is equal to the total ml of SULFURIC ACID SOLUTION used multiplied by 20.

RESULTS:

When testing a 50 ml sample: (Burette reading of both the P and M titration in ml x 20 = ppm Total (P&M) Alkalinity as CaCO_3)

EXAMPLE: 8.0 ml in "P" reading + 6.0 in "M" reading = 14 ml

"P" Alkalinity = $8.0 \text{ ml} \times 20 = 160 \text{ ppm}$

"M" Alkalinity = $14 \times 20 = 280 \text{ ppm}$

NOTE A: If the endpoint color is difficult to see, repeat the entire test using 15 drops of METHYL PURPLE INDICATOR SOLUTION.

NOTE B: Just before the endpoint is reached, the green color fades to a gray color and then becomes dark purple. The endpoint is the first appearance of a permanent purple color.

NOTE C: The "OH" Alkalinity is calculated using the following formula: $(2 \text{ P}-\text{M}) = \text{OH}$

EXAMPLE: $[(2 \times 160 \text{ ppm}) - 280 \text{ ppm}] = 40 \text{ ppm OH Alkalinity}$

REAGENTS AND APPARATUS FOR "P", "M", "OH" ALKALINITY TEST:

Watertech Replacement	Description
1500-Q	Sulfuric Acid Titrating Solution/Qt (1 ml = 20ppm CaCO_3 /50 ml)
1605-B	Phenolphthalein Indicator, 2 oz
3595-B	Methyl Purple Indicator, 2 oz
8010-PC	Burette Assembly/Complete/10 ml
37940	Graduated Cylinder, 50 ml plastic
9005	Casserole Dish, 140 ml
<i>(different sizes available upon request)</i>	

We cannot anticipate all conditions under which this information and our products, or the products of other manufacturers in combination with our products, may be used. We accept no responsibility for results obtained by the application of this information or the safety and suitability of our products, either alone or in combination with other products. Users are advised to make their own tests to determine the safety and suitability of each such product or product combination for their own purposes. Unless otherwise agreed in writing, we sell the products without warranty, and buyers and users assume all responsibility and liability for loss or damage arising from the handling and use of our products, whether used alone or in combination with other products.